





- Baseband transmission is conducted at low frequencies
- Passband transmission is to send the signal at high frequencies
 - Signal is converted to a sinusoidal waveform, e.g.

$$s(t) = A(t) \cos[\omega_0 t + \phi(t)]$$

where ω_0 is called carrier frequency is much higher than the highest frequency of the modulating signals, i.e. messages

 Bits are encoded as a variation of the amplitude, phase, frequency, or some combination of these parameters.
3











Frequency Modulation (FM)

• A frequency modulated (FM) signal is represented by

$$s(t) = \cos\left[\omega_0 t + k_f \int x(t) dt\right]$$

• Assuming that the information bearing signal $x(t) = \cos(\omega_m t)$, the above expression reduces to

$$s(t) = \cos\left[\omega_0 t + \frac{k_f}{\omega_m} \sin(\omega_m t)\right]$$

= $\cos(\omega_0 t) \cos\left(\frac{k_f}{\omega_m} \sin(\omega_m t)\right) - \sin(\omega_0 t) \sin\left(\frac{k_f}{\omega_m} \sin(\omega_m t)\right)$

• For narrow band FM

$$s(t) = \cos(\omega_0 t) - \beta \sin(\omega_0 t) \sin(\omega_m t), \quad \beta = \frac{k_f}{\omega_m} <<1$$
$$= \operatorname{Re}\left\{e^{j\omega_0 t} - \frac{\beta}{2}e^{j\omega_0 t}\left[\frac{1}{2}e^{j\omega_m t} - \frac{1}{2}e^{-j\omega_m t}\right]\right\}$$
$$= \operatorname{Re}\left\{e^{j\omega_0 t}\left[1 + \frac{\beta}{2}e^{j\omega_m t} - \frac{\beta}{2}e^{-j\omega_m t}\right]\right\}$$

9























Coherent Receiver

- Carrier recovery for demodulation
 - Received signal $r(t) = A\cos(\omega_c t + \varphi) + n(t)$
 - Local carrier $\cos(\omega_c t + \hat{\varphi})$
 - Carrier recovery phase lock loop circuit

$$\Delta \varphi = \varphi - \hat{\varphi} \to 0$$

Demodulation leads to recovered baseband signal

$$Y(t) = s(t + \tau) + n(t)$$

- Timing recovery for sampling
 - Align receiver clock with transmitter clock, so that sampling \rightarrow no ISI

 $Y_k = s_k + n_k$

Non-Coherent Receiver

No carrier recovery for demodulation

• Received signal
$$r(t) = A\cos(\omega_c t + \varphi) + n(t)$$

- Local carrier $\cos(\omega_c t + \hat{\varphi})$
- No carrier recovery

$$\Delta \varphi = \phi = \varphi - \hat{\varphi} \neq 0$$

- Demodulation leads to recovered baseband signal $Y(t) = s(t + \tau)e^{j\phi} + n(t)$
- Timing recovery for sampling
 - Align receiver clock with transmitter clock, sampling results in

$$Y_k = s_k e^{j\phi} + n_k$$

could not recover transmitted symbols properly from Y_k











