# CSE 2021 Computer Organization Chapter 3 Arithmetic for Computers


# **Arithmetic for Computers**

- Operations on integers
  - Addition and subtraction
  - Multiplication and division
  - Dealing with overflow
- Floating-point real numbers
  - Representation and operations



#### **Integer Addition & Subtraction**

Addition example: 7 + 6



- Subtraction example: 7-6=7+(-6)
  - Add negation of second operand

+7: 0000 0000 ... 0000 0111

<u>-6: 1111 1111 ... 1111 1010</u>

+1: 0000 0000 ... 0000 0001

2's complement

#### **Addition of Signed Numbers**

More examples below are shown for 4-bit 2's complement arithmetic.

1. 
$$(+5)$$
 0101  $+(+2)$   $+0010$   $0111$ 

$$\begin{array}{cccc}
2. & (-5) & 1011 \\
& +(+2) & +0010 \\
\hline
& (-3) & 1101
\end{array}$$

3. 
$$(+5)$$
 0101  
 $+(-2)$  +1110  
 $(+3)$  1 0011  
ignore the carry


## **Overflow**

Example: 7 + 6 (each number in signed 4-bit)

+ 7: 0111  
+ 6: 0110  
+13: 
$$1101 \rightarrow -3$$
  
Overflow


Overflow if result out of range

Operation	Operand A	Operand B	Result Indicating overflow
A+B	≥0	≥0	<0
A+B	<0	<0	≥0
A-B	≥0	<0	<0
A-B	<0	≥0	≥0




# **MIPS Multiplication**

- Two 32-bit registers for product
  - HI: most-significant 32 bits
  - LO: least-significant 32-bits
- Instructions
  - mult rs, rt
    - 64-bit product in HI/LO
  - mfhi rd / mflo rd
    - Move from HI/LO to rd
    - Can test HI value to see if product overflows 32 bits
  - mul rd, rs, rt
    - Least-significant 32 bits of product -> rd



#### **MIPS Division**

- Use HI/LO registers for result
  - HI: 32-bit remainder
  - LO: 32-bit quotient
- Instructions
  - div rs, rt
  - No overflow or divide-by-0 checking
    - Software must perform checks if required
  - Use mfhi, mflo to access result



# **Floating Point**

- Representation for non-integral numbers
  - Including very small and very large numbers
- Like scientific notation

  - +0.002 × 10<sup>-4</sup> not normalized
     +987.02 × 10<sup>9</sup>
- In binary
  - $\pm 1.xxxxxxx_2 \times 2^{yyyy}$
- Types float and double in C

#### **Floating Point Standard**

- Defined by IEEE Std 754-1985
- Developed in response to divergence of representations
  - Portability issues for scientific code
- Now almost universally adopted
- Two representations
  - Single precision (32-bit)
  - Double precision (64-bit)

# **IEEE Floating-Point Format**

single: 8 bits single: 23 bits double: 11 bits double: 52 bits

S Exponent Fraction

 $X = (-1)^S \times (1 + Fraction) \times 2^{(Exponent-Bias)}$ 

- S: sign bit  $(0 \Rightarrow \text{non-negative}, 1 \Rightarrow \text{negative})$
- Normalize significand: 1.0 ≤ |significand| < 2.0
  - Always has a leading pre-binary-point 1 bit, so no need to represent it explicitly (hidden bit)
  - Significand is Fraction with the "1." restored
- Exponent: excess representation: actual exponent + Bias
  - Ensures exponent is unsigned
  - Single: Bias = 127; Double: Bias = 1023

# **Single-Precision Range**

- Exponents 00000000 and 11111111 reserved
- Smallest value
  - Exponent: 00000001⇒ actual exponent = 1 - 127 = -126
  - Fraction: 000...00 ⇒ significand = 1.0
  - $\pm 1.0 \times 2^{-126} \approx \pm 1.2 \times 10^{-38}$
- Largest value
  - exponent: 11111110⇒ actual exponent = 254 127 = +127
  - Fraction: 111...11 ⇒ significand ≈ 2.0
  - $\pm 2.0 \times 2^{+127} \approx \pm 3.4 \times 10^{+38}$

# **Double-Precision Range**

- Exponents 0000...00 and 1111...11 reserved
- Smallest value
  - Exponent: 00000000001 ⇒ actual exponent = 1 – 1023 = –1022
  - Fraction:  $000...00 \Rightarrow \text{significand} = 1.0$
  - $\pm 1.0 \times 2^{-1022} \approx \pm 2.2 \times 10^{-308}$
- Largest value
  - Exponent: 11111111110 ⇒ actual exponent = 2046 – 1023 = +1023
  - Fraction: 111...11 ⇒ significand ≈ 2.0
  - $\pm 2.0 \times 2^{+1023} \approx \pm 1.8 \times 10^{+308}$

# **Floating-Point Precision**

- Relative precision
  - all fraction bits are significant
  - Single: approx 2<sup>-23</sup>
    - Equivalent to 23 × log<sub>10</sub>2 ≈ 23 × 0.3 ≈ 6 decimal digits of precision
  - Double: approx 2<sup>-52</sup>
    - Equivalent to 52 × log<sub>10</sub>2 ≈ 52 × 0.3 ≈ 16 decimal digits of precision

## **Activity 1**

 Represent (-0.75)<sub>10</sub> in single and double precision of IEEE 754 binary representation

### **Activity 1**

Represent  $(-0.75)_{10}$  in single and double precision of IEEE 754 binary representation

- $-0.75 = (-1)^1 \times 1.1_2 \times 2^{-1}$
- S = 1
- Fraction =  $1000...00_2$
- Exponent = -1 + Bias
  - Single: -1 + 127 = 126 = 011111110<sub>2</sub>
  - Double: -1 + 1023 = 1022 = 011111111110<sub>2</sub>
- Single: 10111111101000...00
- Double: 10111111111101000...00

# **Activity 2**

- What number is represented by the singleprecision float
  - 11000000101000...00

#### **Activity 2**

What number is represented by the singleprecision float

- 11000000101000...00
- S = 1
- Fraction =  $01000...00_2$
- **Exponent = 10000001\_2 = 129**
- $x = (-1)^{1} \times (1 + .01_{2}) \times 2^{(129 127)}$   $= (-1) \times 1.25 \times 2^{2}$  = -5.0

### **Floating-Point Addition**

- Consider a 4-digit decimal example
  - $-9.999 \times 10^{1} + 1.610 \times 10^{-1}$
- 1. Align decimal points
  - Shift number with smaller exponent
  - $-9.999 \times 10^1 + 0.016 \times 10^1$
- 2. Add significands
  - $-9.999 \times 10^{1} + 0.016 \times 10^{1} = 10.015 \times 10^{1}$
- 3. Normalize result & check for over/underflow
  - 1.0015 × 10<sup>2</sup>
- 4. Round and renormalize if necessary
  - 1.002 × 10<sup>2</sup>

#### **Floating-Point Addition**

- Now consider a 4-digit binary example
  - $1.000_2 \times 2^{-1} + -1.110_2 \times 2^{-2} (0.5 + -0.4375)$
- 1. Align binary points
  - Shift number with smaller exponent
  - $1.000_2 \times 2^{-1} + -0.111_2 \times 2^{-1}$
- 2. Add significands
  - $1.000_2 \times 2^{-1} + -0.111_2 \times 2^{-1} = 0.001_2 \times 2^{-1}$
- 3. Normalize result & check for over/underflow
  - $1.000_2 \times 2^{-4}$ , with no over/underflow
- 4. Round and renormalize if necessary
  - $\bullet$  1.000<sub>2</sub> × 2<sup>-4</sup> (no change) = 0.0625

#### **FP Instructions in MIPS**

- FP hardware is coprocessor 1
  - Adjunct processor that extends the ISA
- Separate FP registers
  - **32** single-precision: \$f0, \$f1, ... \$f31
  - Paired for double-precision: \$f0/\$f1, \$f2/\$f3, ...
- FP instructions operate only on FP registers
  - Programs generally don't do integer ops on FP data, or vice versa
  - More registers with minimal code-size impact
- FP load and store instructions
  - lwc1, ldc1, swc1, sdc1
    - e.g., 1dc1 \$f8, 32(\$sp)

#### **FP Instructions in MIPS**

- Single-precision arithmetic
  - add.s, sub.s, mul.s, div.s
    e.g., add.s \$f0, \$f1, \$f6
- Double-precision arithmetic
  - add.d, sub.d, mul.d, div.de.g., mul.d \$f4, \$f4, \$f6
- Single- and double-precision comparison
  - c.xx.s, c.xx.d (xx is eq, 1t, 1e, ...)
  - Sets or clears FP condition-code bite.g. c.lt.s \$f3, \$f4
- Branch on FP condition code true or false
  - bc1t, bc1f
    - e.g., bc1t TargetLabel

#### **Concluding Remarks**

- ISAs support arithmetic
  - Signed and unsigned integers
  - Floating-point approximation to reals
- Bounded range and precision
  - Operations can overflow and underflow
- MIPS ISA
  - Core instructions: 54 most frequently used
    - 100% of SPECINT, 97% of SPECFP
  - Other instructions: less frequent